


Injection transient study using 6-dimensional bunch-by-bunch diagnostic system at SSRF


Yimei Zhou, Bo Gao, Ning Zhang, Yongbin Leng
SSRF BI Group



IBIC 2018

International Beam Instrumentation Conference
Shanghai, China, 9-13 September 2018

- Bunch-by-bunch diagnostic overview
- System Setup & performance
- Application: Injection transient study
- Next Works
- Summary



Bunch-by-bunch study overview

Why bunch-by-bunch diagnostics

For the construction and operation of the machine

Basic requirements for diagnostics:

- Toolkit to monitor beam parameters for machine operation
- Toolkit for machine study
- Complete other measurement requirements demanded by physicists



Not just “follow the orders to be a soldier”

Play a more active role in the accelerator

- The distribution of high energy particles in the three-dimensional space
- The distribution evolution over time



Derive all other parameters from the above measurements

For bunching beam

Bunch-by-bunch diagnostics

What bunch-by-bunch

In the simplest case

Assume:

- Bunching beam
- Gaussian distribution in the three-dimensional space



Six spatial parameters
($x, y, z, \sigma_x, \sigma_y, \sigma_z$) + Charge
(Q) = an independent
bunch

6-dimensional bunch-by-bunch diagnostic system

What benefit from bunch-by-bunch diagnostics

Stable beam parameter monitoring during user operation mode

- **Online monitoring** of stable beam parameters of each bunch such as length, size and charge
- Results can be used to optimize the operation mode

Unstable beam parameter monitoring during user operation mode

- **Transient process capture** and **further analysis of instability** (amplitude, size, phase)
- Instability prediction (long-term data)

Machine study tool

- Much easier to do experimental research of **wake field** and **impedance**

Injection transient process study

- Evaluate **injection process performance** and optimize injection system (repeatability, disturbance)
- Evaluate **the injector performance** and optimize the injector parameter
- Obtain **dynamic parameters** of the storage ring, optimize storage ring operating parameters, and alert abnormal status

How bunch-by-bunch diagnostics



Source	Advantages	Disadvantages
SR light	• Most ideal signal • Contains all beam information	• Limited by the bandwidth of the signal processing system • Not convenient for online extraction of longitudinal information
Button	• Easy to capture and condition signal	• Unable to get transverse size information

SSRF solutions:

- SR light (x, y, σ_x , σ_y) + Button (x, y, z, σ_z)
- Associate the data by **twiss parameters**

Signal conditioning, acquisition system	6D information extraction methods
• Multi-channel simultaneous sampling ($> 4 (x, y) + 2 (z) + 2 (\sigma_z) + 4 \times 2 (\sigma_x, \sigma_y) = 16$ channels) • Sampling frequency $\geq$ RF (500MHz@SSRF) • Analog bandwidth $\geq$ RF/2 (> 500MHz@SSRF, reduce overlap between bunches)	• Transverse position: delta/sum (Δ/Σ) • Transverse size: Gaussian fitting • Longitudinal phase: zero-crossing detection • Longitudinal length: two-frequency method More methods are exploring.....

Roadmap

2012-2015

2013-2016

2014-2017

2015-2017

2017-present

Transverse
position

Longitudinal
length

Transverse
size

Longitudinal
phase

6D
Synchronous
sampling

Oscilloscope


Oscilloscope

Oscilloscope

Oscilloscope


DAQ

Transverse position (x,y)




Button pickups + $\Delta\Sigma$ algorithm
Resolution $\leq 10\mu\text{m}$ (Y.B. Leng, IPAC15)

Longitudinal length (σ_z)



Button pickups + Two-frequency system
Resolution 0.5ps (L.W. Duan, NST, 2017)


Transverse size (σ_x, σ_y)




SR light + PMT array + Gaussian fitting algorithm
(H.J Chen, NST, 2018)

6-dimensional
bunch-by-bunch
diagnostic system

Longitudinal phase (z)




Button pickups + Zero-crossing detection
Resolution $\leq 2\text{ps}$ (Y.M. Zhou, IPAC17)




System setup & performance

6D Bunch-by-Bunch diagnostic system

➤ Synchronization: relies on the same clock and trigger



Beam transverse position subsystem



Multiplier module:
The clock signal is multiplied
to 1GHz,
To facilitate the use of ADQ



Phase shifter2:
BW DC-4.3GHz
Phase adjustment of the clock signal
To ensure the **peak of signal sampled**

Timing System

2Hz Trigger

694kHz Sync.

Multiplier

Phase shifter
BW DC-4.3GHz

ADQ14 Digitizer




NI
PXI box

999.36MHz

TRIG
CLK
A
B
C
D




BW: 1.2GHz
1GSPS/channel
10bits




Phase shifter1:
Ensure **phase coherence**
of the pickup signals

Transverse position data processing (x,y)



Cross section of button-type BPM

Methods:



Algorithm:

Delta/sum algorithm (Δ/Σ)


$$x = k_x \cdot \frac{(V_A(t) + V_D(t)) - (V_B(t) + V_C(t))}{V_A(t) + V_D(t) + V_B(t) + V_C(t)}$$

$$y = k_y \cdot \frac{(V_A(t) + V_B(t)) - (V_C(t) + V_D(t))}{V_A(t) + V_D(t) + V_B(t) + V_C(t)}$$

Constant: $k_x = 19.1$
 $k_y = 13.4$

Limitations:




- System error introduced by sampling phase drift



Performance evaluation (x, y)



- Data collected during daily operation, 230mA, uniform filling
- PCA method used to evaluate measurement uncertainty of transverse position
- Two modes above noise floor stand for synchrotron oscillation coupled by dispersion
- Amplitude of noise floor identified the system resolution
- **Position resolution better than 10 μ m with 0.6 nC bunch charge**



Measurement uncertainty of transverse position

Beam longitudinal phase subsystem

Timing System

2Hz Trigger

694kHz Sync.

Multiplier

Phase shifter
BW DC-4.3GHz

ADQ14 Digitizer

NI
PXI box

999.36MHz

TRIG
CLK
A
B
C
D




BW: 1.2GHz
1GSPS/channel
10bits



Delay lines: (T=100ps)
Ensure sampling with
the same time interval



Phase shifter:
Ensure the **zero-crossing**
point of the sampled signals



Delay line

Power splitter

BW 1-1000MHz

Button pickup

Shielding wall


Beam

2ns




Power splitter:
BW 1-1000MHz

Longitudinal phase data processing (z)




Cross section of button-type BPM

Methods:



Algorithm:

Zero-crossing detection algorithm




$$I(t) = \frac{Q_0}{\sqrt{2\pi}\sigma} \exp\left(-\frac{(t-t_0)^2}{2\sigma^2}\right)$$

$$V(t) = \frac{\pi a^2 Z}{2\pi b \beta c} \cdot \frac{t - t_0}{\sigma^2} \cdot I(t) \cdot F(\delta, \theta)$$

Phase difference




Limitations:



- Algorithm is not applicable when the longitudinal offset is too large

Performance evaluation (z)

- Data collected during daily operation, 230mA, uniform filling
- PCA method used to evaluate measurement uncertainty of longitudinal phase
- Two modes above noise floor stand for synchrotron oscillation
- Amplitude of noise floor identified the system resolution
- **Phase resolution better than 0.8ps with 0.6 nC bunch charge**



Measurement uncertainty of longitudinal phase

Beam transverse size subsystem

Timing System

2Hz Trigger

694kHz Sync.

Multiplier

Phase shifter
BW DC-4.3GHz

ADQ14 Digitizer

NI
PXI box

999.36MHz

P7 P8 P10 P11

TRIG
CLK
A
B
C
D



BW: 1.2GHz
1GSPS/channel
10bits


Signal
Conditioning

P1 P16

PMT

Optical
imaging system

SR light




Signal Front-end
Pickup board:
Convert plug pins
to SMA connector




Amplifier:
BW 50k-1.5GHz
Gain 36dB

PMT array detector:
16 channels
Hamamatsu H10515B

Path 1: interferometer system



Path 2: PMT system




Optical imaging system:

Path1 for system PSF calibration
Path2 for bunch-by-bunch size measurement

- Focus on **horizontal size** measurement
- Be mirror deformed in the vertical direction.


Transverse size data processing (σ_x, σ_y)

Methods:



Algorithm:

Gaussian fitting method



Bunch position


Center intensity

Bunch size

$$y = a \cdot e^{-\frac{(x-b)^2}{2c^2}}$$

New calculation algorithm - Fast

Delta/sum algorithm (Δ/Σ)



$$\text{Centroid} = ((A+B) - (C+D)) / \Sigma$$


$$\text{Size} = ((B+C) - (A+D)) / \Sigma$$

★ A good upgrade direction & need to be verified next step


Limitations:

- Only four sampling points are not suitable for non-Gaussian distribution.


Performance evaluation (σ_x, σ_y)



Transverse size oscillation of different bunches



Standard deviation of 500 samples



Spectrum of different bunches

- **Good enough to capture transverse size oscillation of different bunches during injection**
- **Spectrum showed size variation contributed by multi sources**
- **Standard deviation of 500 samples (measuring constant bunch size) $< 2\mu\text{m}$**

Beam longitudinal length subsystem

Timing System

2Hz Trigger

694kHz Sync.

694kHz Sync.

Multiplier

Phase shifter
BW DC-4.3GHz

Timing
module


ADQ14 Digitizer

NI
PXI box

999.36MHz

TRIG
CLK
A
B
C
D

BW: 1.2GHz
1GSPS/channel
10bits



Mixer: 6-th signal (3GHz)
To output an intermediate
frequency of 500MHz

2.5GHz LO signal
Generated from a programmable
timing module EVAL-ADF4351

BPF
500MHz

BPF
500MHz

2.5GHz
clock

Phase shifter

BPF
3GHz

Power splitter

BW 0.5-4GHz

Button pickup

Shielding wall

Beam


2ns

Band-pass filter:
Center Frequency: 500MHz
Bandwidth: 310-680MHz



Band-pass filter:
Bandwidth: 2700-3100MHz

Longitudinal length data processing (σ_z)



Beam Spectrum at storage ring of SSRF

Methods:

- Enough signal amplitude
- RF component limitation

Choose

$m1=1$ and **$m2=6$**

(about **500 MHz** and **3 GHz**)
as working frequencies

Algorithm:

Two-frequency method

Due to two channels


transfer function difference and **limited bandwidth**

$$\sigma = \sqrt{\frac{2}{m_2^2 \omega_0^2 - m_1^2 \omega_0^2} \ln \left(K_1 \frac{V_1}{V_2} + K_2 \right)}$$

m_2, m_1, ω_0 are
theoretically knowable

$V1/V2$ is measured from
two-frequency system

No theoretical analytic
solution for **$K1$** and **$K2$**
The two coefficients **can be**
calibrated by Streak Camera




Two-frequency system coefficient
calibration by Steak Camera

Limitations:


- Only two frequency points are also not
suitable for non-Gaussian distribution

Performance evaluation (σ_z)




**Bunch length has been measured
in very large dynamic range
(30pC to 6nC)**

Results of small charge
accidentally obtained by moving
the scraper toward beam center



Bunch length shortening during beam loss



Bunch length measurement with stored single
bunch beam

New method agreed with Streak Camera very well

Charge (Q)

Charge information acquisition:

- Charge (Q) is in Gaussian distribution

$$I(t) = \frac{Q_0}{\sqrt{2\pi}\sigma} \exp\left(-\frac{t^2}{2\sigma^2}\right)$$


- Get the peak value of the BPM signal or SR signal

$$V_{peak} = K_Q \cdot Q_0$$

$$K_Q = k_0 Z \sqrt{\frac{e}{2\pi}} \frac{1}{\sigma^2}$$


K_Q is calibrated with DCCT readings in single bunch operation

- All subsystems can get bunch charge
- The results are consistent with each other



Refilled charge acquisition:

$$\text{Refilled charge} = \text{Charge after injection} - \text{Charge before injection}$$



Bunch charge before and after injection



Injection transient study: Data analysis method

Why injection transient study

□ Change machine parameters

compare the measured value
with the expected value

(Ideal experiment for beam instability study,
Require dedicated machine study time)

□ Injection transient process

separate stored bunch and
refilled bunch


(frequently observe in the user operation
mode at SSRF)

• Betatron Damping oscillation

← mismatch of kickers, also injector and storage ring

• Synchrotron Damping oscillation

← mismatch of injector and storage ring



- Refilled charge / Q_r
- Betatron amplitude / A_r
- Synchrotron amplitude / z_m
- Synchrotron damping time / τ
- Initial position in phase space / φ_0

- Stored charge / Q_s
- Transverse tune / ν_x, ν_y
- Betatron amplitude / A_s
- Betatron damping time / L_x

Challenges

Biggest

Separation of stored charge and refilled charge

(Refilled bunch parameter acquisition)


Transverse position	Adjacent bunch position + charge-weighted averaging
Longitudinal phase	Adjacent bunch phase + charge-weighted averaging
Transverse size	• Four sampling points are not enough to obtain the refilled bunch size.
Longitudinal length	• Two frequency points are not enough to obtain the refilled bunch length.

➤ **Bunch length of the stored charge is unchanged during the injection process.**

Focus on

(x, y, z, σ_x)

Refilled bunch longitudinal phase extraction



Signal fusion model with different phase of the refilled bunch

Charge-weighted averaging + Zero-crossing detection

$$V_m = V_s + V_r \quad Q_m = Q_s + Q_r \quad t = \frac{V_1}{V_1 - V_2} \cdot T$$

Refilled bunch phase
Extraction Formula:

$$t_r = \frac{Q_s}{Q_r} \left[t_m \left(1 + \frac{Q_r}{Q_s} \right) - t_s \right]$$

Q_s : Obtained from the averaged charge of stored bunches


Refilled charge
acquisition:

$$Q_r = \text{Charge after injection} - \text{Charge before injection}$$

t_m : Measured phase by zero-crossing detection method

Stored phase
acquisition:


$$t_s = \text{Mean}(\text{Phase after injection}, \text{Phase before injection})$$



Refilled bunch transverse position extraction

Charge-weighted averaging + Δ/Σ algorithm

$$V_m = V_s + V_r \quad Q_m = Q_s + Q_r \quad X = \frac{V_1 - V_2}{V_1 + V_2}$$



Refilled bunch position
Extraction Formula:

$$X_r = \frac{Q_s}{Q_r} \left[X_m \left(1 + \frac{Q_r}{Q_s} \right) - X_s \right]$$


Q_s : Obtained from the **averaged charge of stored bunches**

Refilled charge acquisition:

$$Q_r = \text{Charge after injection} - \text{Charge before injection}$$


X_m : Measured position by **Δ/Σ algorithm**

X_s : Stored bunch position obtained by **interpolation of neighbor bunches**




Injection transient study: A typical injection event


Raw data of injection capturing




Raw data of transverse position
from **Button BPM**




Raw data of longitudinal phase
from **Button BPM**




Raw data of transverse size
from **SR light**



Negative peak of each channel




Around the zero-crossing point




Negative peak of each channel


Refilled bunch: transverse position



Measured combined bunch position (Xm)



Stored bunch position (Xs)




Refilled bunch position (Xr)

$$X_r = \frac{Q_s}{Q_r} \left(X_m \left(1 + \frac{Q_r}{Q_s} \right) - X_s \right)$$


Injector performance evaluation:

Peak to peak value of refilled bunch position indicates the transverse mismatch between injector and storage ring


Refilled bunch: longitudinal position



Measured combined bunch phase (t_m)



Stored bunch phase (t_s)



Refilled bunch phase (t_r)

$$t_r = \frac{Q_s}{Q_r} \left(t_m \left(1 + \frac{Q_r}{Q_s} \right) - t_s \right)$$

Injector performance evaluation:


Oscillation amplitude of refilled bunch phase indicates the longitudinal mismatch between injector and storage ring

Refilled bunch: Synchrotron damping

Longitudinal phase fitting method is used to study the **synchrotron damping oscillation**.

$$z_d = z_m \sin(\omega t + \varphi_0) \cdot e^{-\frac{t}{\tau}}$$


z_m : Maximum oscillation amplitude
 φ_0 : Initial phase
 τ : Damping time
 $\alpha_s = \frac{1}{\tau}$
 $\omega = \sqrt{\Omega^2 - \alpha_s^2}$
 Ω : Synchrotron frequency (~ 0.0072)



Storage Ring performance evaluation:


- Synchrotron damping time can be retrieved from the refilled bunch phase oscillation.
- A flag to monitor longitudinal dynamic behavior of storage ring.

The fitting results agreed with the measured results very well.




Stored bunches : transverse position

PCA modes separation



Singular values of different modes


horizontal position PCA




The first four principal components of the oscillation after injection

Betatron oscillation introduced by :

- mismatch of **kicker field** (typical damping oscillation)
- **Wake-field effects** (oscillation expansion after transmission)



Betatron amplitude of each bunch




BPM position oscillation of different bunches

Different bunch showed different oscillation amplitude.


- Largest amplitude **bunch #397**: mostly contributed by **kicker mismatch**
- Smallest amplitude **bunch #3**: contributed by **kicker mismatch and wake-field effects**

Stored bunch: transverse size (σ_x)


- Same analysis method is used for transverse size measurement
- Data from **SR light**, captured by PMT detector.



Betatron amplitude of each bunch




Transverse position oscillation from the SR light




Horizontal size oscillation of different bunches

Qualitative analysis

In good agreement with the position results from the button BPM.



Bunch #520 and Bunch 719: combined effects of kicker field mismatch and wake-field



Injection transient study: long term data

Long term data

**Stored
bunch train**

**Refilled
bunch**

**Reflect the match
between the injector
and the storage ring**

Synchrotron amplitude

Betatron amplitude

Betatron amplitude

Betatron damping time

**Reflect the dynamic
behavior of the
storage ring**


Synchrotron damping time

Betatron amplitude distribution

Tune distribution


**Wake field and impedance study
Stability and repeatability of the storage ring**

Refilled bunch parameters



Refilled bunch charge

10 pC ~ 50 pC




Refilled bunch transverse position (p-p)

25 mm ~ 35 mm

Mismatch between the injector and the storage ring


- **Large variation**
- **Can be improved by optimizing injector**




Refilled bunch longitudinal osc. amplitude

105 ps ~ 158 ps


Stored bunches Betatron oscillation



The evolution of horizontal betatron oscillation



Projection distribution in the horizontal direction




Average betatron amplitude distribution over time.


Hor.
300~450

- **Stable distribution** : basically not change over time
- **Changed amplitude value**: gradually decrease

Tune distribution (ν_x, ν_y)



The evolution of **horizontal** tune distribution.




The evolution of **vertical** tune distribution.

- Data obtained from the stored bunch position.
- Tune distribution is stable
- Tune drift exists, the machine needs to be improved


Transverse tune:
(0.23, 0.30)

Betatron damping time (L_x)



$$y \propto \exp\left(-\frac{x}{L_x}\right)$$

Betatron damping time




The evolution of Betatron damping time.

- Obtained by the exponential fitting
- Useful for the **betatron oscillation study**
- Reflect the **transverse dynamics** of the storage ring


Betatron damping time: **1~2ms**

Synchrotron damping time (τ)



$$y \propto \exp\left(-\frac{t}{\tau}\right)$$

Synchrotron damping time




The evolution of synchrotron damping time.

- Obtained by the exponential fitting
- Useful for the **synchrotron oscillation study**
- Reflect the **longitudinal dynamics** of the storage ring

Synchrotron damping time


2.5ms~3ms



Next works

More channels for bunch size


- 8-16 channels upgrade
- To achieve non-Gaussian distribution measurement



Multi-channel bunch size online system based on commercial DAQ


More channels for bunch length

- To achieve multi-frequency measurement
- To achieve non-Gaussian distribution measurement



Multi-frequency bunch length online system based on commercial DAQ

Intelligent trigger



6-dimensional bunch-by-bunch diagnostic system architecture

Intelligent trigger system to capture random beam instability events

Summary



- ***The 6-dimensional diagnostic system*** with bunch-by-bunch capability is successfully implemented at SSRF.
- The **beam position, size, phase and length** during the injection transient process are all measured by the system.
- With the **refilled bunch extraction algorithm**, the refilled bunch position and phase can be obtained. And the **dynamic parameters** of the storage ring also can be obtained from the injection transient study.
- **DAQ need to be upgraded** and **intelligent trigger mode** based on FPGA will be implemented. After upgrading, this system will be more useful for physicists to capture bunch-by-bunch data when unstable beam condition shows up.

Acknowledge




- Appreciated for the support from National Natural Science Foundation of China (No. 11375255 and No. 11375254)
- Appreciated for the help from beam physics group and beam operation group of SSRF in beam experiment
- Appreciated for the work from Zhichu Chen, Yong Yang, Liwu Duan, Hanjiao Chen
- Appreciated for the guidance of my supervisor Yongbin Leng



Thanks for your attention

Contact: zhouyimei@sinap.ac.cn



中国科学院上海应用物理研究所
Shanghai Institute of Applied Physics, Chinese Academy of Sciences